

# Kwikbit Premium Service Quick Start

January 20, 2022

Welcome to Kwikbit Internet Premium Service. Use these instructions to get connected quickly.



## Equipment provided:

- EdgeCore EAP101 Wi-Fi access point.
- CAT6 Ethernet cable.
- Power supply.

## Additional Help:

Kwikbit is committed to providing our customers with high quality technical support.

 [support@kwikbitinternet.com](mailto:support@kwikbitinternet.com)

 [kwikbitinternet.com](http://kwikbitinternet.com)

## Installation tips:

- **Position the EAP101 in a clear, uncluttered central location.** Avoid placing the access point in closets, on the floor, in tight bookshelves or close to sources of interference such as Bluetooth devices, microwaves or baby monitors.
- **For running the Ethernet cable into the RV through the RV slide gasket:** Run the RV slide in 4 to 6 inches. Slip the cable into the RV between the inner and outer gaskets. Inside the RV, pull the cable to the access point location. Run the RV slide out to seal it and it will hold the cable in place.

## Installation

- 1 Plug one end of the Ethernet cable into the pedestal jack at your RV lot space.
- 2 Run the cable into your RV. A common way to do this is through the gaskets of the RV slide, see the tip above.
- 3 Place the Wi-Fi access point in a central, unblocked location that is above the floor, inside your RV.
- 4 Plug the power supply into the EAP101 in the 12Vdc port shown below and connect it to a wall outlet.



- 5 Plug the Ethernet cable into the port labeled Uplink(PoE).
- 6 After 2 minutes connect your Internet-enabled devices to the access point using the Wi-Fi SSID and passcode on the access point label. For a hard-wired Ethernet connection, use the LAN ports on the EAP101 access point. Cat 6 Ethernet cable is recommended.

